

Flex Switch I and II

Wireless Switching

Flex Switch I and II are battery operated wireless switches that offer years of security and convenience on its' easily replaced standard 12v battery. Mounting is simple: clean surface to be attached, remove VHB tape cover and install.

FLEX SWITCH I



Screw Mount

FLEX SWITCH II




Adhesive Mount



Compact In Size

Smaller profile to fit where you want it, when you need it.



Stylish

Easily painted to match any color trim or decor.



Installs Easily

No drilling or screws. Flex Switch II mounts easily on most surfaces, including granite, with its' unique adhesive backing.



Universal

Communicates with all HDC controllers to lock and unlock any door with power locks, including compartments.

